

How to install Your Little Free Library

Materials

- 8 ft - 4" x 4" post
- 2 ft - 2" x 6" piece of wood
- 6 - 2 1/2" lag screws
- 3" exterior lag screws
- 3" lag bolts

1. To start, you will need an 8 ft. - 4" x 4" treated post. Any kind will work, but cedar tone is our favorite.

2. Cut the post 5 ft. long.

3. With the remaining piece make side angle braces. Cut each piece 10 3/4" long and cut 45° angles on the ends.

4. Cut a platform as wide as the Little Free Library out of the 2" x 6" piece of wood.

5. Mount the angled braces to the 5 ft. post with 3" exterior lag screws and then attach the 2" x 6" platform using 6- 2 1/2" lag screws. First, pre-drill a slightly smaller hole to make it easier to install the lag screw. Use 3" lag screws to enhance the holding power.

6. Dig a 24" deep hole and install the post. Make sure to use a level and tamp the dirt hard with a shovel to secure the post.

7. Drill 6 holes through the top of the Little Free Library. The holes need to match up with the post platform. Use the 6- 2 1/2" lag screws to attach the platform to the library.

8. You are done! Now take a picture of you and your friends by your Little Free Library and register it via our website: www.littlefreelibrary.org.

9. Build another Little Free Library. People always say, you can't just build one!

